


LDK 4502

HDTV Camera Base Station



User's Guide



3922 496 48741 St.24

Declaration of Conformity

We, Thomson Broadcast Solutions Nederland B.V., Kapittelweg 10, 4827 HG Breda, The Netherlands declare under our sole responsibility that this product is in compliance with the following standards:

- EN60065 : Safety
- EN55103-1 : EMC (Emission)
- EN55103-2 : EMC (Immunity)

following the provisions of:

- a. the Safety Directives 73/23/EEC and 93/68/EEC
- b. the EMC Directives 89/336/EEC and 93/68/EEC

FCC Class A Statement

This product generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause interference to radio communications.

It has been tested and found to comply with the limits for a class A computing device pursuant to Subpart J of part 15 of FCC rules, which are designed to provide reasonable protection against such interference when operated in a commercial environment.

Operation of this product in a residential area is likely to cause interference in which case the user at his own expense will be required to take whatever measures may be required to correct the interference.

Copyright

Für diese Unterlage behalten wir uns alle Rechte vor (Gemäß DIN 34). Technische Änderungen im Zuge der Weiterentwicklung vorbehalten.

Copying of this document and giving it to others, and the use or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights are reserved in the event of the grant of a patent or the registration of a utility model or design. Liable to technical alterations in the course of further development.

Toute communication ou reproduction de ce document, toute exploitation ou communication de son contenu sont interdites, sauf autorisation expresse. Tout manquement à cette règle est illicite et expose son auteur au versement de dommages et intérêts. Tous nos droits sont réservés pour le cas de la délivrance d'un modèle d'utilité. Sous réserve de modification au cours de l'évolution technique.

HDTV Camera Base Station

User's Guide

Contents

About This Manual ii

Safety Instructions 1-1
Safety Summary 1-2
Cautions and Warnings 1-2
Earthing 1-3

Installation 2-1
Unpacking/Transport/Storage 2-2
Dimensions 2-3
Connectors and Cables 2-4
Intercom 2-14
Voice Mail 2-20
Private Data 2-21
MCP Available 2-22
Specifications 2-23

Operating Instructions 3-1
Introduction 3-2
Front panel 3-3
Set-up 3-4
Using the Menu System 3-5

Menu System A3-1
System Menu Structure A3-2
List of Abbreviations A3-8

Replacements 4-1
Introduction 4-2
Power 4-2
Opening The Base Station 4-4
Replacing Dust Filters 4-5

Diagnostics 5-1
Diagnostic LED Indications 5-2
Triax diagnostic indications 5-3
Board identification 5-4
Sync/Encoder HD board status 5-5

Service Parts 6-1
Parts list & Exploded Views 6-2

About This Manual

Service policy

The Camera Base Station is a sophisticated base station containing state-of-the-art electronic components which are designed to provide long-life operation without the need for maintenance. With this in mind, the service policy of Thomson Multimedia Broadcast Solutions endeavours to ensure that help will be quickly on hand in the unlikely event of anything going wrong. The guiding principles of the Thomson Multimedia Broadcast Solutions first line maintenance philosophy are speed and cost effectiveness. First line maintenance is dedicated to keeping your base station operational, despite a fault, by module replacement and the replacement of minor mechanical parts by the user.

Purpose of this manual

The provision of correct information is the first step in ensuring the operational integrity of the base station. Information on the operation of the base station is contained in Section 3 of the manual.

This User's Guide is an integral part of the service policy. It ensures that you will be able to operate, install and set-up your base station to meet the requirements of your environment. The information on the installation of the base station is contained in Section 2 of the manual. The remaining sections of the manual provide first line service information so that suitably qualified service personnel can detect and repair faults, normally by module replacement.

Because of the complexity of some of the components, second line service can only be carried out at the specially equipped service centres and information concerning second line maintenance is not supplied in this manual.

Intended audience

The manual is intended as a guide to those with a working knowledge of camera systems and installation techniques. The first line detection and repair of faults requires a general knowledge of test and measurement techniques.

Structure of this manual

The manual is divided into eight different sections:

Section 1: Safety Instructions

Outlines the safety precautions that must be taken when using the base station.

Section 2: Installation

Gives instructions on the integration of the base station into the operating environment and the customization of certain functions.

Section 3: Operating instructions

Explains how to program the menu system for your personal preferences. The menu structure and the methods of function selection are also explained. An appendix to this section lists all the menu functions.

Section 4: Replacements

Gives information on the replacement of components at first line level.

Section 5: Diagnostics

Gives a guide to diagnostic messages and procedures for fault-finding.

Identification and Status

To indicate the status of a drawing, a box with the numbers 0 to 9 is shown in the bottom-right of the drawing. The number that is crossed-out is the status number of the drawing. For example, in the illustration below, the status is 1.

0	1	2	3	4
5	6	7	8	9

A sticker is used on the units themselves to identify them and to indicate their status. For example, in the illustration below, the top line is the 12-digit number that identifies the unit type.

3922 406 88991
00121107 00 01

The first four digits of the number on the second line represent a date code (year, week); the next four digits represent the serial number for that week.

The number in the grey area indicates the status of the unit. The last two digits represent the number that will be given to the next status. However, if these two digits are contained in a box, then this is the current status. For example, in the illustration above, the current status of the unit is 01.

Section 1

Safety Instructions

This section outlines the precautions that must be taken into account when using the LDK 20(S) Studio Camera.

Contents

Safety Summary	1-2	Earthing	1-3
Cautions and Warnings	1-2		

Safety Summary

This information is intended as a guide for trained and qualified personnel who are aware of the dangers involved in handling potentially hazardous electrical/electronic equipment. It is not intended to contain a complete list of all safety precautions which should be observed by personnel in using this or other electronic equipment.

The installation, maintenance and service of this equipment involves risks both to personnel and equipment and must be performed only by qualified personnel exercising due care.

Personnel engaged in the installation, operation, maintenance or servicing of this equipment are urged to become familiar with First Aid theory and practices.

During installation and operation of this equipment, local building safety and fire protection standards must be observed.

Before connecting the equipment to the power supply of the installation, the proper functioning of the protective earth lead of the installation needs to be verified.

Whenever it is likely that safe operation is impaired, the apparatus must be made inoperative and secured against any unintended operation. The appropriate servicing authority must then be informed. For example, safety is likely to be impaired if the apparatus fails to perform the intended function or shows visible damage.

This product has been designed and tested according to EN60065.

Cautions and Warnings

When performing service, be sure to read and comply with the warning and caution notices appearing in the manuals. Warnings indicate danger that requires correct procedures or practices to prevent death or injury to personnel. Cautions indicate procedures or practices that should be followed to prevent damage or destruction to equipment or property.

WARNING

THE CURRENT AND VOLTAGES PRESENT IN THIS EQUIPMENT ARE DANGEROUS. ALL PERSONNEL MUST AT ALL TIMES FOLLOW THE SAFETY REGULATIONS.

ALWAYS DISCONNECT POWER BEFORE REMOVING COVERS OR PANELS.

ALWAYS DISCHARGE HIGH VOLTAGE POINTS BEFORE SERVICING.

NEVER MAKE INTERNAL ADJUSTMENTS, PERFORM MAINTENANCE OR SERVICE WHEN ALONE OR WHEN FATIGUED.

IN CASE OF AN EMERGENCY ENSURE THAT THE POWER IS DISCONNECTED.

ANY INTERRUPTION OF THE PROTECTION CONDUCTOR INSIDE OR OUTSIDE THE APPARATUS, OR DISCONNECTION OF THE PROTECTIVE EARTH TERMINAL, IS LIKELY TO MAKE THE APPARATUS DANGEROUS. INTENTIONAL INTERRUPTION IS PROHIBITED.

FOR SAFETY REASONS THE CPU MUST BE MOUNTED IN A 19-inch RACK WHICH HAS SAFETY COVERS ACCORDING TO IEC65.

WHEN TWO CPUs ARE MOUNTED ABOVE EACH OTHER THE MINIMUM DISTANCE BETWEEN THEM MUST BE 50MM OR THE RACK MUST BE FORCE-AIR COOLED.

USE ONLY FUSES OF THE TYPE AND RATING SPECIFIED.

CAUTION

To prevent risk of overheating, ventilate the product correctly.

Connect the product only to a power source with the specified voltage rating.

Only connect a Triax cable from the LDK 6 camera family to an LDK 6 CPU. Never connect it to any other base station.

Never connect the Triax cable from a camera to a CPU of a different family; never connect the LDK family to the TTV family.

Do not allow system ground currents to exceed 1.5A in the outer shield of the triax cable or 0.2A in other cable shields.

It is strictly prohibited to short circuit the inner and outer shields of a triax cable used to connect a camera to a base station.

Earthing

Symbol	Colour	Explanation
	Red	High voltage terminal at which a voltage, with respect to an other terminal, exists or may be adjusted to 1000V or more.
	Yellow/Black	Live part.
	Yellow/Black	This marking indicates that the operator must refer to an explanation in the Instruction Manual, or that a specific component must be replaced by the component specified in the documentation for safety reasons.
	White/Black	Protective earth (ground) terminal.

Cathode ray tubes


Components marked on the circuit diagram are critical for safety and include those specified to comply with X-ray emission standards for units using cathode ray tubes and those specified for compliance with various regulations regarding spurious radiation emission.

When servicing units that use cathode ray tubes (CRTs), the cathode ray tubes themselves, the high voltage circuits and related circuits are specifically chosen so that they comply with recognized codes pertaining to X-ray emission.

Consequently, when servicing, replace the cathode ray tubes and other parts with specified parts only. Do not attempt to modify these circuits as any unauthorized modification can increase the high voltage value and cause X-ray emission from the cathode ray tube.

Handle the cathode ray tube only when wearing shatterproof goggles and after discharging the high voltage completely.

The rear of a CPU has two separate screw terminals for protective earth (PE) and video earth (VE).



These are normally connected by a metal strap. The protective earth terminal is internally connected to the protective earth conductor of the power cable. If required, the central earth connection wire of the studio can be connected to terminal PE.

In normal circumstances the connection between the protective earth and the video earth should not be broken.

The metal strap may be removed only if the studio (or OB van) is equipped with separate protective and video earth systems. Under these circumstances the video earth terminal must be connected to the central functional earth potential (video earth) of the studio. This earth potential should have functional protective and noiseless earth (FPE) qualities as stated in the VDE regulation 0800/part2. A low impedance interconnection of both earth conductors must be provided at the central studio earthing point.

WARNING

THE UNIT MUST ALWAYS BE CONNECTED TO PROTECTIVE EARTH.

Mains Lead Wiring for UK Users

The wires in the mains lead are coloured in accordance with the following code:

GREEN AND YELLOW	-	EARTH
BLUE	-	NEUTRAL
BROWN	-	LIVE

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

- The wire coloured GREEN AND YELLOW must be connected to the terminal on the plug marked with the letter E or by the safety earth symbol or coloured GREEN or GREEN AND YELLOW.
- The wire coloured BROWN must be connected to the terminal marked with the letter L or coloured RED.
- The wire coloured BLUE must be connected to the terminal marked with the letter N or coloured BLACK.

Ensure that your equipment is connected correctly - if you are in any doubt consult a qualified electrician.

Section 2

Installation

This section provides information which is relevant when the base station is to be used for the first time. Packing and unpacking instructions together with information on the integration of the base station into your studio system are provided. The procedures for the customization of certain hardware functions and connector information is also provided.

Contents

Unpacking/Transport/Storage	2-2	Voice Mail	2-20
Dimensions	2-3	Private Data	2-21
Connectors and Cables	2-4	MCP Available	2-22
Intercom	2-14	Specifications	2-23

Unpacking/Transport/Storage

Unpacking

Inspect the shipping container for evidence of damage immediately after receipt. If the shipping container or cushioning material is damaged, it should be kept until the contents of the shipment have been checked for completeness and the units have been checked mechanically and electrically.

The shipping container should be placed upright and opened from the top.

Remove the cushioning material and lift out the contents.

The contents of the shipment should be checked against the packing list. If the contents are incomplete, if there is mechanical damage or defect, or if the units do not perform correctly when unpacked, notify your Thomson Multimedia Broadcast Solutions sales or service centre within eight days. If the shipping container shows signs of damage or stress, notify the carrier as well.

Transport

If a unit is being returned to Thomson Multimedia Broadcast Solutions for servicing, try to use the containers and materials of the original packaging. Attach a tag indicating the type of service required, return address, model number, full serial number and the return number which will be supplied by your Thomson Multimedia Broadcast Solutions service centre.

If the original packing can no longer be used, the following general instructions should be used for repacking with commercially available materials:

- a. Wrap unit in heavy paper or plastic.
- b. Use strong shipping container.
- c. Use a layer of shock-absorbing material around all sides of the unit to provide firm cushioning and prevent movement inside container.
- d. Seal shipping container securely.
- e. Mark shipping container FRAGILE to ensure careful handling.

Storage

The unit may be stored (non-operating condition) in environments within the following limits:

Temperature:	-40°C to +70°C
Humidity:	Max. 90% (non condensing)
Altitude:	max. 50.0000 feet



When stored, the unit should be protected from temperature extremes which may cause condensation, and should also be protected from high levels of dust.

Dimensions


Dimensions:

Width: 438 mm
Height: 88 mm
Depth: 510 mm max. (excluding triax connector + cable)

Weight: approx. 17kg.




Connectors and Cables




Triax connector orientation

The triax connector can be mounted to suit your cable run.



Intercom Connector (I/Com) - Panel View



15-pin female, shielded cable

1. Prod. out (4-wire out, 2-wire in/out)
2. Prod. in (4-wire only)
3. Prod. in shield (4-wire only)
4. ENG in (4-wire only)
5. ENG out (4-wire out, 2-wire in/out)
6. Progr. in (4-wire only)
7. Progr. in shield (4-wire only)
8. Housing
9. prod. out return (4-wire out, 2-wire in/out)
10. prod. in return (4-wire only)
11. ENG in shield (4-wire only)
12. ENG in return (4-wire only)
13. ENG out return (4-wire out, 2-wire in/out)
14. Progr. in return (4-wire only)
15. Housing

Shield of cable to the pin marked housing.

4-wire:

Output signals: level +6dBu or 0dBu selectable output impedance 50 ohm (max), symmetrical

Input signals: level +6dBu or 0dBu selectable impedance 9 Kohm (min), symmetrical


2-wire: level 0dBu
load impedance: 200 ohm
maximum DC level = 40 V

X374


15-pin female

Panel part number 2411 022 06239
Cable part number 2411 022 05168


2 - Wire configuration



4 - Wire configuration



RS232 Connector (RS232) - Panel View




1. SPARE
2. RS-RXD - Receive Data
3. RS-TXD - Transmit Data
4. RS-DTR - Data Terminal Ready
5. RS-DGND - Signal Ground
6. RS-DSR - Data bSet Ready
7. RS-RTS - Request To Send
8. RS-CTS - Clear To Send
9. +12V

X7 Data Board **9-pin male**
X379 Signal Connector Board

Panel part number 2422 025 12962
Serial Interface Cable 4822 872 03413

Auxiliary Connector (Aux) - Panel View



9-pin female, shielded cable


1. +5V
2. AN 0
3. PRIVATE DATA OUT
4. PRIVATE DATA IN
5. Housing (Shield of cable to this pin)
6. GND
7. AN 1
8. PRIVATE DATA OUT RET
9. PRIVATE DATA IN RET

Shield of cable directly to the connector housing.

X371

9-pin female

Panel part number 2411 022 06238
Cable part number 2411 022 05284



AUX (private data BS - CAM)

: "0"= 0V +/- 0.5V

: "1"= 5V +/- 0.5V


Rout = 150 ohm

Baudrate typ 2400 bits/sec

max 4800 bits/sec

Duty cycle difference between input and output is max 5%

Signalling Connector (Sign) - Panel View



- 15-pin male, shielded cable
- Prev. out ext. (relay contact < 10 ohm)
 - Call out ext. (relay contact < 10 ohm)
 - Iso in ext. (dry contact)
 - On-Air in ext (dry contact)
 - Call in ext. (dry contact)
 - Audio 1 level (analogue input voltage 0V to +5V, see figure below)


- 64 dB -----	0V
- 58 dB -----	+0.7V
- 52 dB -----	+1.3V
- 46 dB -----	+1.9V
- 40 dB -----	+2.5V
- 34 dB -----	+3.1V
- 28 dB -----	+3.7V
- 22 dB -----	+4.3V

X 370 15-pin male; panel view


Panel part number 2411 022 05292

Cable part number 2411 022 06157


- +5 Vdc; OCP
 - Housing
 - Prev. out ext. return
 - Call out ext. return
 - Iso in ext. return
 - On-Air in ext. return
 - Call in ext. return
 - Audio 2 level (see pin 6)
 - GND
- Shield of cable to the pin marked housing.



When the Iso, On-Air or Call signal is provided by a dry contact, connect the outputs to the signalling connector as shown in this figure.




When the Iso, On-Air or Call signal is provided by a dry contact with a common return connector connect the outputs to the signalling connector as shown in this figure.




When the Iso, On-Air or Call signal is provided by a DC output voltage connect the outputs to the signalling connector as shown in this figure.

Notes: The Iso, On-Air and Call signal is off if the input voltage is 5..24 VDC. The Iso, On-Air and Call signal is on if the input voltage is 0VDC. The X370 Signalling inputs are not galvanically separated. We recommend using dry contacts and when these are not available using galvanically separated DC voltage outputs.



Audio Connector - Panel View



1. shield
2. Audio +
3. Audio -

Microphone impedance >200 ohm

Sensitivity remote controlled via base station:

range: -64 to -22 dBu.


Shield of cable directly to the connector housing.

X338/X339

XLR 3-pin male

Panel part number 2422 026 02985
Cable part number 2432 026 00185

Data Connector - Panel View



4-pin male, shielded cable

- A. Data
- B. Data not
- C. Not connected
- D. Shield


Shield of cable to the pin marked housing.

X368 / X378

4-pin male

Panel part number 2411 020 11367
Cable part number 2411 020 12025

Mains Input Connector - Panel View



Eurostyle 3-pin male

- 1. Neutral
- 2. Line
- 3. Earth


Mains input voltage: 230 Vac or 115 Vac

Fuses: 4AT 10AT

Mains frequency: 47 to 63 Hz

Power consumption: 320 Watt

Link Connector - Panel View



3-pin female, shielded cable


- 1. Data link
- 2. Data link N
- 3. Housing

Shield of cable to the pin marked housing.

X380	Fischer 3-pin female
Panel part number	3922 040 02881
Cable part number	2432 026 00274

FOR FUTURE USE ONLY


Headset Connectors - Panel View



X574
Panel part number
Cable part number

Tuchel 5-pin female


- Headset Connector**
Tuchel 5-pin female
- 1. Telephone left
 - 2. Telephone return
 - 3. Microphone
 - 4. Microphone return
 - 5/6. Telephone right
- Shield of cable directly to the connector housing.



X574
Panel part number
Cable part number

Tuchel 6-pin female


- Tuchel 6-pin female
- 1. Telephone left
 - 2. Telephone return
 - 3. Microphone
 - 4. Microphone return
 - 5. Telephone right
 - 6. Telephone return
- Shield of cable directly to the connector housing.



X574
Panel part number
Cable part number

XLR 5-pin female
2422 026

- XLR 5-pin female
- 1. Microphone return
 - 2. Microphone
 - 3. Telephone return
 - 4. Telephone left
 - 5. Telephone right
- Microphone level -64dBu
Microphone impedance 200 ohm
Telephone level +6dBm nominal
Telephone output impedance <50 ohm
Shield of cable directly to the connector housing.




X574
Panel part number
Cable part number

XLR 7-pin female
3922 494 16571

- XLR 7-pin female
- 1. not connected
 - 2. Return
 - 3. ENG Telephone right
 - 4. Return
 - 5. ENG Telephone left
 - 6. Return
 - 7. ENG Microphone

Triax Connectors - Panel View



Triax Connectors

Fischer

- 1. Inner pin: Signals + power
- 2. Inner shield: Return
- 3. Outer shield: Base Station housing

Trilock

- 1. Inner pin: Signals + power
- 2. Inner shield: Return
- 3. Outer shield: Base Station housing

ARD

- 1. Inner pin: Signals + power
- 2. Inner shield: Return
- 3. Outer shield: Base Station housing

X540	Fischer male
Panel part number	3922 407 30531
X540	Trilock female
Panel part number	3922 407 30551
X540	ARD female
Panel part number	3922 407 30571
X540	LEMO 3 female
Panel part number	3922 407 30631
X540	LEMO 4 female
Panel part number	3922 407 30591
X540	LEMO BBC male
Panel part number	3922 407 30611

The panel partnumbers are the connectors including the assembly.

Lemo 3

- 1. Inner pin: Signals + power
- 2. Inner shield: Return
- 3. Outer shield: Base Station housing

Lemo 4

- 1. Inner pin: Signals + power
- 2. Inner shield: Return
- 3. Outer shield: Base Station housing

Lemo BBC

- 1. Inner pin: Signals + power
- 2. Inner shield: Return
- 3. Outer shield: Base Station housing

Intercom


The intercom functions available are determined by the configuration of the base station. The Headset board and the Audio/Intercom board are optional. This results in four possible configurations:

1. Headset board present - Audio/Intercom board absent
2. Headset board absent - Audio/Intercom board present
3. Both boards present
4. Both boards absent

If both boards are absent then there are no intercom facilities available. The other configurations are shown in the figures below.

Depending on your camera configuration, consult the cross-reference tables to see which menu positions should be used for both camera and base station menus for routing the intercom signals.

Headset board present - Audio/Intercom board absent in Base Station




Headset board present - Audio/Intercom board absent in Base Station

TO FROM	Tracker Headset	Camera Headset	BS Headset
Tracker Mic (Phantom Power !)	Tracker Output = ENG Channel Camera system menu: Install \ Intercom \ Track mic to ≠ Off Install \ Intercom \ Track Source = Side	Camera system menu: Install \ Intercom \ Track mic to ≠ Off Install \ Intercom \ Cam track ≠ Off Install \ Intercom \ Cam level > 0	Camera system menu: Install \ Intercom \ Track mic to ≠ Off BS system menu: Audio/Intercom \ ENG headset \ Tracker to headset = On Audio/Intercom \ ENG headset \ Tracker volume > 0 BS front: Intercom selection switch = Cam + Floor
Camera Mic (Phantom Power !)	CAM Channel Tracker Output = Camera Channel Cam Mic = On* Camera system menu: Install \ Intercom \ Cam Mic to = CH1 ENG Channel Tracker Output = ENG Channel Camera system menu: Install \ Intercom \ Track Source = Side Install \ Intercom \ Cam Mic to = Ch2	Camera system menu: Install \ Intercom \ Cam Mic = On Install \ Intercom \ Side tone > 0	Camera system menu: Install \ Intercom \ Cam mic to = CH1 (If = CH2, then monitoring via floor) BS system menu: Audio/Intercom \ ENG headset \ Cam to headset = On Audio/Intercom \ ENG headset \ Cam volume > 0 Audio/Intercom \ ENG headset \ Floor to headset = On BS front: Intercom selection switch = Cam + Floor
BS Headset Mic (Phantom Power !)	Tracker Output = ENG Channel Camera system menu: Install \ Intercom \ Track Source = ENG BS system menu: Audio/Intercom \ ENG Headset \ Mic to ENG-Cam = On	Camera system menu: Install \ Intercom \ Cam engineering ≠ Off BS system menu: Audio/Intercom \ ENG Headset \ Mic to ENG-Cam = On	BS system menu: Audio/Intercom \ ENG headset \ Sidetone > 0

* Other ways to switch on camera microphone:

- Camera: Start button = On
- Camera: Intercom Routing Switch = ENG or PROD

Audio/Intercom board present - Headset board absent in Base Station



Audio/Intercom board present - Headset board absent in Base Station


FROM	TO	Tracker Headset	Camera Headset	Studio PROD	Studio ENG
Tracker Mic (Phantom Power !)		Tracker box = ENG Channel Camera system menu: Install \ Intercom \ Track mic to ≠ Off Install \ Intercom \ Track Source = Side	Camera system menu: Install \ Intercom \ Track mic to ≠ Off Install \ Intercom \ Cam track ≠ Off Install \ Intercom \ Cam level > 0	Camera system menu: Install \ Intercom \ Track mic to = All or Prod BS system menu: Audio/Intercom \ Intercom \ Isolate \ Isolate = Syst	Camera system menu: Install \ Intercom \ Track mic to = All or ENG BS system menu: Audio/Intercom \ Intercom \ Isolate \ Isolate = Syst
Camera Mic (Phantom Power !)		CAM Channel Tracker box = Camera Channel Cam Mic = On* Camera system menu: Install \ Intercom \ Cam Mic to = CHI ENG Channel Tracker box = ENG Channel Camera system menu: Install \ Intercom \ Track Source = Side Install \ Intercom \ Cam Mic to = Ch2	Camera system menu: Install \ Intercom \ Cam Mic = On Install \ Intercom \ Side tone > 0	BS system menu: Audio/Intercom \ Intercom \ Isolate \ Isolate = Syst Camera intercom routing switch = Prod (or camera start button = on)	BS system menu: Audio/Intercom \ Intercom \ Isolate \ Isolate = Syst Camera intercom routing switch = ENG
Studio PROD		Tracker box = PROD Channel	Camera system menu: Install \ Intercom \ Cam production ≠ Off	Not available	Not available
Studio ENG		Tracker box = ENG Channel Camera system menu: Install \ Intercom \ Track Source = ENG	Camera system menu: Install \ Intercom \ Cam engineering ≠ Off	Not available	Not available
Studio PROG		Tracker box = PROG Channel	Camera system menu: Install \ Intercom \ Cam program ≠ Off	Not available	Not available

* Other ways to switch on camera microphone:

- Camera: Start button = On
- Camera: Intercom Routing Switch = ENG or PROD

Audio/Intercom board and Headset board present in Base Station

3. Headset board present - Audio/Intercom board present




Audio/Intercom board and Headset board present in Base Station

FROM TO	Tracker Headset	Camera Headset	BS Headset	Studio PROD	Studio ENG
Tracker Mic (Phantom Power !)	Tracker box = ENG Channel Camera system menu: Install \ Intercom \ Track mic to ≠ Off Install \ Intercom \ Track Source = Side	Camera system menu: Install \ Intercom \ Track mic to ≠ Off Install \ Intercom \ Cam track ≠ Off Install \ Intercom \ Cam level > 0	Camera system menu: Install \ Intercom \ Track mic to ≠ Off BS system menu: Audio/Intercom \ ENG headset \ Tracker to headset = On Audio/Intercom \ ENG headset \ Tracker volume > 0 BS front: Intercom selection switch = Cam + Floor	Camera system menu: Install \ Intercom \ Track mic to = All (or Prod) BS system menu: Audio/Intercom \ Isolate \ Isolate ≠ Isol	Camera system menu: Install \ Intercom \ Track mic to = All (or Eng) BS system menu: Audio/Intercom \ Isolate \ Isolate ≠ Isol
Camera Mic (Phantom Power !)	CAM Channel Tracker box = Camera Channel Cam Mic = On* Camera system menu: Install \ Intercom \ Cam Mic to = CHI ENG Channel Tracker box = ENG Channel Camera system menu: Install \ Intercom \ Track Source = Side Install \ Intercom \ Cam Mic to = Ch2	Camera system menu: Install \ Intercom \ Cam Mic = On Install \ Intercom \ Side tone > 0	Camera system menu: Install \ Intercom \ Cam mic to = CHI (if = CH2, then monitoring via floor) BS system menu: Audio/Intercom \ ENG headset \ Cam to headset = On Audio/Intercom \ ENG headset \ Cam volume > 0 Audio/Intercom \ ENG headset \ Floor to headset = On BS front: Intercom selection switch = Cam + Floor	BS system menu: Audio/Intercom \ Isolate \ Isolate ≠ Isol Camera intercom routing switch = PROD	BS system menu: Audio/Intercom \ Isolate \ Isolate ≠ Isol Camera intercom routing switch = ENG
BS Headset Mic (Phantom Power !)	Tracker box = ENG Channel Camera system menu: Install \ Intercom \ Track Source = ENG BS system menu: Audio/Intercom \ ENG Headset \ Mic to ENG-Cam = On	Camera system menu: Install \ Intercom \ Cam Engineering ≠ Off BS system menu: Audio/Intercom \ ENG Headset \ Mic to ENG-Cam = On	BS system menu: Audio/Intercom \ ENG headset \ Sidetone > 0	Not available	BS system menu: Audio/Intercom \ Isolate \ Isolate ≠ Isol Audio/Intercom \ ENG Headset \ Mic Eng-Out = On
Studio PROD	Tracker box = PROD Channel	Camera system menu: Install \ Intercom \ Cam Production ≠ Off	BS front: Intercom selection switch = PROD	Not available	Not available
Studio ENG	Tracker box = ENG Channel	Camera system menu: Install \ Intercom \ Cam Engineering ≠ Off	BS front: Intercom selection switch = ENG	Not available	Not available
Studio PROG	Tracker box = PROG Channel	Camera system menu: Install \ Intercom \ Cam Program ≠ Off	BS front: Intercom selection switch = PROG	Not available	Not available

* Other ways to switch on camera microphone:
 • Camera: Start button = On
 • Camera: Intercom Routing Switch = ENG or PROD

Voice Mail



Voice Mail is an intercom message storage function.

Note: Voice mail is only available if the Base Station menu item *Audio/Intercom \ Intercom \ Call* is set to Voice.

Recording

Recording starts automatically at the start of a message. A new message erases the previous recorded message. The maximum message length is 16 seconds. Longer messages are recorded in a retroloop. Only the last 16 seconds are available for playback.


Select the intercom channels to be recorded via the Base

Station menu items *Audio/Intercom \ Intercom \ Voice mail \ Record ENG, PROD and PROG*.

Note: The voice mail box can only contain one message. If voice mail recording starts from an other intercom channel the previous message is erased.

Listening to the message

Push the camera call button to start playing out the recorded voice mail to the camera headset. Push the call button again to stop playing the voice mail message.



Private data channels can be used for the transmission of serial data via the triax cable. For example, electronic scriptboard or character data for a video display unit can be transmitted to the camera.

The tracker microphone intercom channel is used for the data channel from camera head to Base Station. The program intercom channel is used for the data channel from Base Station to camera head. The input and output signals are available on the auxiliary connectors of the camera and Base Station (for camera see the connectors and cables section). If a channel is used for private data, then of course the original functions are no longer available.

To select the function of the Base Station to camera channel set the Base Station menu item *Audio/Intercom \ Private Data \ PROG Channel* to Priva.

To select the function of the Camera to Base Station channel set the Base Station menu item *Audio/Intercom \ Private Data \ Tracker Channel* to Priva.

Remember that the propagation-delay times are different for different triax cable lengths, especially if a return signal is involved. At maximum lengths of 2400 metres the total delay is at least 25 μ sec. and can be more than 30 μ sec, depending on the type of triax cable.

Data signal specifications

Baudrate: 2400

Input level: TLL, possible RS232

Input impedance: 100Kohm

Output impedance: ~300 ohm

Max load: ~1Kohm

MCP Available

When no MCP is available it might occur that some functions are in an undesirable position, for example, a lock on the upper part of the OCP. To prevent this happening, set the Base Station menu item *System \ MCP Available* to No when an MCP is not available.

The functions affected by this setting and their state are as follows (if the item value is set to MCP Available = No):

Variable black stretch (Yes/No)	Yes
Variable gamma (Yes/No)	Yes
Variable Flare (Yes/No)	Yes
Saturation (Yes/No)	Yes
White clipper (Yes/No)	Yes
Knee slope (Yes/No)	Yes
Knee point (Yes/No)	Yes
Iris(Normal/Reverse)	Normal
OCP lock (Upper/Total)	Total
Intercom (System/Isolate)	System
Audio (External/MCP)	External
Aspect Ratio (External/MCP)	External
Aspect Ratio (4:3/16:9)	4:3
Autolight (Yes/No)	Yes

Specifications

LDK 4502/00

HDTV Base Station

General

Dimensions (WxHxD)	438 (19" rack) x 88 (2RU) x 510mm. (17.2 x 3.5 x 20.1 inch)
Operating temperature	-20 °C to +50 °C (-4 °F to 122 °F)
Storage temperature	-40 °C to +70 °C (-40 °F to 158 °F)
Operating humidity	Max. 90% (non condensing)
Shock resistance	Max. 10G (transport), Max. 2G (operating)
Altitude	Max. 50,000 ft
Weight	17.0 kg. (37.5 lbs.) fully equipped with options

Transmission

Typical. cable length	1,000 m. (3,281 ft) (14 mm./0.55" triax cable)
Bandwidth	30/ 15/ 15 MHz., Y/Cr/Cb

Connectors

Teleprompter in	BNC 1x (and loop-through output), 1.0Vp-p, 75Ω
Reference in	BNC 1x (and loop-through output), 1.0Vp-p, 75Ω HD tri-level sync or SD Black Burst
HD-SDI out	BNC 3x, 0.8Vp-p, 75 Ω, SMPTE 292M, 1080i or 720p at 59.94 or 50Hz
Text out	BNC 1x, 1.0Vp-p, 75 Ω (VBS)
Composite video out	BNC 1x, 1.0Vp-p, 75 Ω (CVBS, w/ or w/o text, for viewing purposes)
Signalling in/out	D-sub 15-pin, male Preview, Green tally (call), dry contact, Yellow tally (ISO), dry contact Red tally (on-air), dry contact Remote audio level control (22-64dB), DC
Auxiliary in/out	D-sub 9-pin, female An0, 0-5Vdc in, output on camera head An1, 0-5Vdc in, 16:9 < 0.8 Vdc in, 4:3 > 2.4Vdc in Private data in/ out, 2.4kB TTL (RS-232)
RS-232	D-sub 9-pin, male (RXD, TXD, DTR, DSR, RTS, CTS)
Control data Link	4- pin, male (2-wire camera control bus) 3- pin, female (Feature box control link)

LDK 4510 POWER MODULES

LDK 4510/10	AC/DC power module for studio and portable camera heads
Power requirement	AC 115V/230V +/- 15%, 47 to 63Hz
Power connector	IEC type, 3-pin male
Power consumption	470VA or 270Watts max. with studio camera head; 360VA or 210Watts max. with port. camera head
Utility power	150VA or 150Watts max. on studio camera head; 80VA or 80Watts max. on port. camera head

LDK 4521 HDTV TRIAX MODULES

LDK 4521/10	TriaxHD Module with Fischer triax connector
LDK 4521/20	TriaxHD Module with Tri-Lock triax connector
LDK 4521/30	TriaxHD Module with ARD triax connector
LDK 4521/40	TriaxHD Module with Lemo 4 triax connector
LDK 4521/50	TriaxHD Module with Lemo BBC triax connector
LDK 4521/60	TriaxHD Module with Lemo 3 triax connector

LDK 4530 EXTERNAL VIDEO IN MODULES

LDK 4530/10	External video input module
External video in	BNC 2x, 1.0Vp-p, 75Ω (loop-through) (CVBS or VBS)

LDK 4531 VIDEO OUT MODULES

LDK 4531/20	SDTV output HD module
SDI out	BNC 3x, 0.8Vp-p, 75 Ω, SMPTE 259M, ITU-R, BT.601
Analog out	BNC 3x, R, G, B or Y, Pr, Pb, or 3x CVBS (menu selection): - RGB out: 3x 0.7Vp-p (+/- 1%), 75 Ω - Y, Pr, Pb: 3x 0.7Vp-p (+/- 1%), 75 Ω - CVBS out: 3x 1.0Vp-p (+/- 1%), 75 Ω Frequency response 0.1 to 5.75MHz (+0.5dB/-1dB) K factor Less than 2%

LDK 4540 AUDIO & INTERCOM MODULES

LDK 4540/10	2 ch. audio & 2/4-wire intercom
Audio out	XLR- 3 2x, 0/+6dBu (+/-1.5dB, max. 18dBu, 600 Ω, Gain Max. 70dB)
Frequency response	40Hz to 15kHz, (+1/-3dB, 1kHz, -10dBu output level)
Distortion	Less than 0.5% (100Hz/ 1kHz, +6dBu out, 600 Ω)
S/N ratio	58dB (unweighted RMS)
Intercom in/out	D- sub 15- pin, female (program in, production in/out, engineering in/out in: 0 or 6dBu (max. 6 or 12dBu), 9kΩ, out: 0 or 6dBu (+/- 2dB, max 12dBu), 600Ω)
Frequency response	150Hz to 6kHz (1kHz, -10dBu output level)
Distortion	Less than 2% (1kHz, +12dBu level)

LDK 4541 Engineering intercom module

LDK 4541/10	XLR-5 (female) engineering intercom module
LDK 4541/20	Tuchel 6-pin engineering intercom module
LDK 4541/30	Tuchel 5-pin engineering intercom module
LDK 4541/40	XLR-7 (female) engineering intercom module
Frequency response	(6dBu, +/- 2dB, max 12dBu, 25-400 Ω) 150Hz to 6kHz, +/- 3dB (0dB, 1kHz, -10dBu output level)
S/N ratio	46dB (unweighted RMS)
Phantom power	+12Vdc (+/- 1V), menu selectable

LDK 4560 MONITORING MODULES

LDK 4560/20	Monitoring HD module (with WFM, PXM and analog HDTV out)
PXM video out	BNC 1x, 1.0Vp-p, 75 Ω, SMPTE 274M or SMPTE 296M (depending on acquisition format); R, G, B or Y (menu selection) with HD tri-level SYNC
WFM video out	BNC 1x, 1.0Vp-p, 75 Ω, SMPTE 274M or SMPTE 296M (depending on acquisition format); R, G, B or Y (menu selection) with HD tri-level sync.
Analog HDTV out	VGA-type D-connector, 15-pin, female, with R, G, B, H-sync and V-sync
Frequency response	0.1 to 30MHz (+0.5dB/- 1dB)

Section 3

Operating Instructions

This section describes the structure of the camera base station control system. This section explains how to control and program the menu system and how to set up the menu system to suit your personal preferences. The menu structure and the methods of function selection are also explained. The appendix shows the contents of the menu system.

Contents

Introduction	3-2	Set-up	3-4
Front panel	3-3	Using the Menu System	3-5

Introduction

The flexible design of the base station means that it can be integrated into a variety of configurations in studios or OB vans. To make full use of its extensive functionality it provides many facilities for setting it up. Once set up, operation is virtually transparent.

We recommend that you spend time using the various controls and displays in order to fully discover the wide range of features. Read the instructions in this section carefully but also feel free to examine the various menus in detail. In this way you will learn quickly to intuitively use the system.

Simple set-up

The Rotary/Push button behind the left front cover can be used to control some basic set-up functions. It can also be used to navigate through the menu system.

Menu System

The menu system is used for setting up and configuring the base station. As there are a large number of functions and set-up options available, it may require some time for you to become familiar with them all.


OCP menu control

Although the Rotary/Push button can be used to navigate through the menu system, it is more convenient to use the OCP connected to the Base Station. (Refer to the OCP user guide to find out how to do this.)

Viewing the menu

The System Menu video signal is available on the Text output of the base station. The System Menu text can also be superimposed on the CVBS output if desired.

Front panel



1 Display

During normal operation the display shows the number of the camera connected to the Base Station.

When the set-up control (located behind the left front cover) is activated, the display shows a two letter code to identify the set-up function (see Set-Up).

The display can be switched on or off via the Base Station menu system.

2 Intercom volume control

Adjusts the volume of the selected intercom channel being monitored on the connector below.

3 Intercom selection switch

Use this switch to select the intercom channel that is monitored on the connector below.

4 Intercom connector

Connect a headset to this connector to monitor the selected intercom channel.

5 Camera Communication

This green LED lights when the communications between Camera and Base Station are OK.

6 On Air and ISO indicators

The red LED lights when the Camera is On Air. If the Camera is selected as ISO Camera the yellow LED lights.

7 Power Switch

Switches the power supply to the Base Station on and off. A built-in light lights to indicate that the power is ON.

8 Base Station

This green LED lights when the Base Station is operationally ready.


9 Camera indicators

This bicolour TEST LED lights red or yellow to indicate the Camera and Triax status:

- Red lights continuously – Triax short circuit.
- Red flashes – Triax open circuit.
- Yellow – Camera power switched off with the Operational or Master Control Panel.

This green CONNECTED LED lights when the Camera is connected and the Camera power switch is On.

Set-up



Set-up items

There are four items that can be accessed via the set-up Rotary/Push button on the Data Board:

- Camera number (CA)
- Subcarrier adjustment (SC)
- H-phase (HP)
- System menu (NN)

Remove the left front cover to access the Rotary/Push button on the Data Board.

Rotate the button to the left or right to select the required item. The display shows the abbreviation of the current item.

Camera Number (CA)

When CA is displayed, push the Rotary/Push button to enter the selection mode. Rotate the button to the left or right to select an available camera number. Push the Rotary/Push button to set the new camera number. The Base Station automatically resets and the new camera number is shown in the display.

Subcarrier (SC)

When SC is displayed, push the Rotary/Push button to enter the Subcarrier adjustment mode. Rotate the button to the left or right to shift the Subcarrier phase. If you continue to rotate

the button, the shift change occurs in bigger steps. Push the Rotary/Push button to leave the Subcarrier adjustment mode.

H-Phase (HP)

When HP is displayed, push the Rotary/Push button to enter the H-Phase adjustment mode. Rotate the button to the left or right to shift the H-Phase. If you continue to rotate the button, the shift change occurs in bigger steps. Push the Rotary/Push button to leave the H-Phase adjustment mode.

System Menu (NN)

When NN is displayed, push the Rotary/Push button twice to enter the System Menu. The Rotary/Push button can be used to navigate through the menu system, however, it is more convenient to use the OCP connected to the Base Station. (Refer to the OCP user guide to find out how to do this.)

The System Menu video signal is available on the Text output of the base station. The System Menu text can also be superimposed on the CVBS and the Monitor output if desired.

Using the Menu System

Entering the Systems menu


The system functions of the base station are grouped into menus and sub-menus. Rotate the Rotary/Push button to the left or right to select the Systems Menu. The display shows the abbreviation NN. Push the Rotary/Push button twice to enter. The Main menu appears on the monitor.

Note:

Navigating the system menu is also possible with the LDK4628 and LDK4629 Operational Control Panels. Refer to their respective User's Guide for information on how to do this.

The main menu screen shows five items and the name of the menu. One more item is hidden but becomes visible when you scroll down.

A cursor shows your position in the menu. The Rotary/Push button moves the cursor up and down.




Finding your way

Use the Rotary/Push button to move the cursor through the menu items. If a double arrow (>>) is visible, then pressing the Rotary/Push button brings you one level lower in the menu system. Only five items are visible in each menu. Scroll up or down to see any additional items.

When you first enter a menu (other than the main menu) the cursor is positioned next to the first item.

The TOP and PREVIOUS entries are not immediately visible but are located above the first item. Use the Rotary control to scroll up to them.

- Select TOP to bring you back to the MAIN menu.
- Select PREVIOUS to go back to the menu that you were in before the current one.



The SYSTEM menu above shows the items displayed when you first enter the menu and the other items that are available by scrolling up or down with the Rotary control.

Leaving the Systems Menu

If you are deep within the menu structure, follow these steps to leave:

- a. If necessary move the cursor to the left most column with the Rotary/Push button.
- b. Scroll upwards until the cursor points to TOP (this is the main menu).
- c. Press the Rotary/Push button. The cursor now points to the Menu off item of the MAIN menu.
- d. Press the Rotary/Push button to leave the system menu.

This is the recommended way of leaving the system menu.

The menu system disappears after a few seconds when you stop navigating. (This delay can be programmed in the *MONITORING/MENU* menu.) However, when you enter the system menu again you enter at the last position of the cursor and not at the top of main menu.

To prevent confusion the next time you enter the system menu, it is advisable to leave the system menu by returning to the main menu (TOP) and selecting *MENU OFF*.

Making changes

To find out where to change a function, consult the List of System Menu Functions at the end of this section to find out under which menu group or subgroup the function is located.

If the cursor points to an item (and there are no double arrows to indicate a sub-menu) then the item pointed to has a value.

The value can be:

- a toggle value (only two values)
- a list value (more than two values)
- an analogue value (variable from 00 to 99)

or unavailable (---).

If the value is unavailable it cannot be changed. This is indicated by three dashes (---). This can occur, for example, when a function is switched off. The analogue values associated with that function are then unavailable.

If there are only two values associated with the function, then pressing the Rotary/Push button toggles between these two values.

If a value is displayed next to a function that is one of several possible values, then pressing the Rotary/Push button places the cursor in a list menu indicating the value currently selected. Use the Rotary/Push button to point to a new value. Press the Rotary/Push button to return the cursor to the function list.

If an analogue value is displayed next to a function name, then pressing the Rotary/Push button places the cursor in front of the value and the Rotary/Push button is used to change the analogue value. Press the Rotary/Push button to return the cursor to the function list.

Undoing changes

If you make changes to the settings in the Systems menu and you decide not to keep them, use the Recall File function to recall a standard or stored set of values for the parameters. These files are available in the FILES menu.

Menu Structure

Access to the functions on these menus is determined by the user level that has been set. The menus are as follows:

Main (top) menu

The top menu gives access to the other menus.

Video menu

The video menu contains those functions which affect the picture quality.

Monitoring menu

This menu contains the functions which determine how items in the video monitor are displayed.

Audio/Intercom menu

The functions contained under this menu control various aspects of audio and intercom.

SDTV menu

The SDTV menu contains the functions that are used to set up the SDTV output settings.

System menu

This menu contains the functions that are used to set up the general configuration and for carrying out adjustments and calibrations of the Base Station.

Files menu

This menu allows values to be stored in System and operator files, and allows these files to be recalled as required.

Diagnostic menu

The diagnostic menu is designed to provide information on the current status of the Base Station.

User Levels

The menu items are divided into two user levels. The operator level "O" is default accessible. Menu items with user level Install "I" are only accessible if the menu level is set to Install.

To enter the Install level proceed as follows:

- a. Enter the menu.
- b. Navigate to the *Monitoring \ Menu \ Menu level* Item.
- c. Set the Menu level to Inst.

The purpose of the user levels is to restrict the set of functions which can be changed by whoever is using the Base Station. In this way a the danger of the operator accidentally changing critical functions while shooting is reduced.

The system Menu Structure paragraph of this section indicates which functions are available at each user level.

Video menu - Special features

Auto lighting

The Auto Lighting item of the the video menu compensates for variations in the frequency of the power supply used for gas discharge lamps (fluorescent or HMI lighting).

The frequency of power supply generators can vary from the nominal value. This variation affects the lighting which in turn affects the colour balance. If camera system and lighting are supplied by the same power source, then the base station auto lighting function can automatically adjust the exposure to follow the variations and maintain a constant colour balance. This correction only works when the camera exposure time is set to the 50Hz or 60Hz position.

Section 3 -Appendix

Menu System

Contents

System Menu Structure	A3-2	List of Abbreviations	A3-8
-----------------------------	------	-----------------------------	------

System Menu Structure

The system Menu tables present the functions ordered in the logical divisions of the menu system itself with additional information in the columns:

- User level column
The User level column indicates the functions that are available with different user levels.
- Values column
All available choices are listed for a function.
- Blocked if column
Lists the conditions that block the function.
- Default column
The default column lists the values of the functions when a camera is delivered.
- Files column
The File column indicates where the value of the function is stored; in the operator file or in the system file or not at all.
- Comments column
The Comments column list information about the function.

MAIN Menu			
Menu text	User		Comments
<Menu Off>	O	I	
Video >>	O	I	
Monitoring >>	O	I	
Audio/Intercom >>	O	I	
SDTV >>	O	I	
System >>	O	I	
Files >>	O	I	
Diagnostics >>	O	I	

VIDEO Menu							
Menu text	User		Values	Default	Blocked if	File	Comments
Chroma >>	O	I	On,Off	On	-	Scene	Add colour information to the CVBS signals
Colour Bar >>							
Colour Bar	O	I	On,Off	Off	-	Scene	-
Colour Bar Type		I	SMPTE,Full	SMPTE	-	System	Change white bar level in colour bar
Ext Black Clamp		I	0..99	50		System	

MONITORING Menu							
Menu text	User		Values	Default	Blocked if	File	Comments
Monitoring Source	O	I	R,G,B,Y	Y	-	Scene	Select signal on Monitoring output
Menu >>							
Display	O	I	On,Time	Time	-	Operator	Time out superimposed menu text on or off
Menu Time	O	I	5...99	10	-	Operator	Time out duration superimposed menu text
Menu Level	O	I	Oper,Inst	Inst	-	-	Set menu level to Operator or Install level
Statusbar >>							
Studio >>							
Studio	O	I	On,Off	Off	-	Operator	Display studio name in Statusbar
Name	O	I	[String]	-	-	-	Edit studio name
Operator >>							
Operator	O	I	On,Off	Off	-	Operator	Display camera operator name in statusbar
Name	O	I	[String]	-	-	-	Edit camera operator name

AUDIO/INTERCOM Menu							
Menu text	User		Values	Default	Blocked if	File	Comments
Audio >>							
Audio Level 1		I	0dB,6dB	6dB	-	System	Studio audio system level input 1
Audio Level 2		I	0dB,6dB	6dB	-	System	Studio audio system level input 2
Intercom >>							
Private Data >>							Consult Section "Private Data" for detailed information
Tracker Channel		I	Inter,Priva	Inter		System	Private data channel from Camera to Base Station *
Prog Channel		I	Inter,Priva	Inter	-	System	Private data channel from Base Station to Camera *
Isolate >>							No Intercom communication from Camera to Base Station (Studio)
Source	O	I	Local,Rmote	Local	-	Operator	Local = Setting available in Base Station Menu, Rmote = Setting available with MCP
Isolate		I	Isol,Syst	Syst	Source=Rmote	Install	Isol = Isolate, Syst = Isolate is off
ENG >>							
Wire Mode		I	2 wire,4 wire	4 wire	-	System	Standard studio intercom system setting
Side Tone	O	I	0..99	50	-	Operator	-
level	O	I	0dB,6dB	6dB	ENG Wire Mode=2	Operator	Standard studio intercom system setting
In Ref Level		I	0..99	50	-	System	Input intercom level signal from studio
Out Ref Level	O	I	0..99	50	-	Operator	Output intercom level to studio
PROD >>							
Wire Mode		I	2 wire,4 wire	4 wire	-	System	Standard studio intercom system setting
Side Tone		I	0..99	50	-	System	-
Level	O	I	0dB,6dB	6dB	PROD Wire Mode=2	Operator	Standard studio intercom system setting
In Ref Level		I	0..99	50	-	System	Input intercom level signal from studio
Out Ref Level		I	0..99	50	-	System	Output intercom level to studio
PROG >>							
Wire Mode		I	2 wire,4 wire	4 wire	-	System	Standard studio intercom system setting
Level	O	I	0dB,6dB	6dB	PROG Wire Mode=2	Operator	Standard studio intercom system setting
In Ref Level		I	0..99	50	-	System	Input intercom level signal from studio
ENG Headset >>							Settings for the optional headset module
Phantom Power	O	I	On,Off	Off	-	Operator	12V DC Phantom power
Mic Level	O	I	0dB,20dB	20dB	-	Operator	Headset microphone sensitivity
Side Tone	O	I	0..99	50	-	Operator	Headset side ton level
Mic to Headset		I	On,Off	On	ENG Wire Mode=2	System	Side tone on/off
CAM to Headset	O	I	On,Off	On	-	Operator	Camera ENG channel to headset
CAM Volume	O	I	0..99	50	-	Operator	Camera ENG channel to headset level
Tracker to Headset	O	I	On,Off	On	-	Operator	Tracker ENG channel to headset

AUDIO/INTERCOM Menu (Continued)							
Menu text	User		Values	Default	Blocked if	File	Comments
Tracker Volume	O	I	0..99	50	-	Operator	Tracker ENG channel to headset level
Mic Eng-Out	O	I	On,Off	On	-	Operator	Headset to basestation ENG output
Mic to Eng-Cam	O	I	On,Off	On	-	Operator	Headset to camera ENG channel
Call		I	Call,Voice	Call	-	Operator	Set to Voice if Voice Mail functionality is required. (The Call function is still available if Call is set to Voice)
Voice Mail >>							See Section 3 "Voice Mail"
Record ENG	O	I	On,Off	On	Call is not Voice	Operator	Intercom messages from the ENG channel to the camera are recorded.
Record PROD	O	I	On,Off	On	call is not Voice	Operator	Intercom messages from the PROD channel to the camera are recorded.
Record PROG	O	I	On,Off	On	call is not Voice	Operator	Intercom messages from the PROG channel to the camera are recorded.

* The LDK 100 and LDK 200 cameras with LDK5430 triax adapter follow these settings automatically.
For the LDK 10(p), LDK 20(p) and LDK 2000(p) cameras dip- switches in the camera have to be set.

SDTV Menu							
Menu text	User		Values	Default	Blocked if	File	Comments
Chroma >>							
Chroma	O	I	On,Off	On	-	Operator	Add colour information to the CVBS signals
Level		I	0..99	50	-	System	
Contour							SDTV contour settings
Contour	O	I	On,Off	On	-	Scene	-
Source	O	I	G,R,Y,AVG	Y	-	Scene	-
Level	O	I	0..99	50	-	Scene	-
Vertical Level	O	I	0..99	50	-	Scene	-
Noise Slicer	O	I	0..99	6	-	Scene	-
Course/fine	O	I	0..99	25	-	Scene	-
Level Dependence	O	I	0..99	50	-	Scene	-
Soft Contour	O	I	On,Off	On	-	Scene	-
Soft Contour Level	O	I	0..99	70	-	Scene	-
Notch							
Notch		I	On,Off	Off	-	Scene	Suppress visible distortion in hatch patterns
Level		I	0..99	50	-	Scene	-
Video Output		I	GRB,YPrPb,CVBS, Off	CVBS	-	System	Select signal type at the Options outputs
Aspect Ratio		I	16:9,4:3	16:09	-	-	SDTV Aspect Ratio

SYSTEM Menu							
Menu text	User		Values	Default	Blocked if	File	Comments
Camera Number	O	I	1..15	15	-	-	Set camera number
Camera Power	O	I	On,Off	On	-	Operator	Switch the power to the camera
MCP Available		I	Yes,No	Yes	-	Operator	See Section "No MCP Available"
Yellow On Air	O	I	Std,Indep	Std	-	System	Yellow On Air mode
Timing							
H Phase Course	O	I	0..99	50	No ext. Ref.	System	No external reference signal is provided at the reference input connector.
H Phase Fine	O	I	0..99	50	No ext. Ref.	System	See comments H Phase Course
Subcarrier Course	O	I	0,90,180,270	180	No ext. Ref.	System	See comments H Phase Course
Subcarrier Fine	O	I	0..99	50	No ext. Ref.	System	See comments H Phase Course
Subc H Phase Course		I	0,90,180,270	180	Ext. Ref	System	A external reference signal is provided at the reference input connector
Subc H Phase Fine		I	0..99	50	Ext. Ref	System	See comments Subc H Phase Course
Clock >>							
Day		I	1..31	1	-	-	-
Month		I	Jan,Feb..Dec	Jan	-	-	-
Year		I	0..99	0	-	-	-
Hour		I	0..23	0	-	-	-
Minute		I	0..59	0	-	-	-
Video Mode		I	10i59,7p59,10i50,7p50	10i59	-	-	Video modes: 1080i59.94, 720p59.94, 1080i50 and 720p50
Teleprompter		I	On,Off	Off	-	System	-

FILES Menu						
Menu text	User		Values	Default	Blocked if	Comments
User Operator Files >>						The "File" column of a menu item indicated with "Operator" is stored in a Operator file.
Operator File	O	I	O_BS1..O_BS4	BS1		Select Operator file
Recall	O	I	exec	-		Recall Operator file
Store	O	I	exec	-		Store Operator file
Std. Operator Files >>						Standard Operator files
Operator File	O	I	CUST,FACT	CUST		Set the standard Operator file to customer or to factory.
Recall	O	I	exec	-		Recall standard Operator file
Store		I	exec	-	Std. Operator file=FACT	Store standard customer Operator file. It is not possible to overwrite the factory file
User System Files >>						The "File" column of a menu item indicated with "System" is stored in a System file.
System File		I	S_BS1..S_BS4	-		Select System file
Recall		I	exec	-		Recall System file
Store		I	exec	-		Store System file
Std. System Files >>						Standard System files
System File		I	CUST,FACT	CUST		Set the standard System file to customer or to factory.
Recall		I	exec	-		Recall standard System file
Store		I	exec	-	Std. System file=FACT	Store standard customer System file. It is not possible to overwrite the factory file

DIAGNOSTICS Menu						
Menu text	User	Values	Default	Blocked if	File	Comments
Board ID >>						
Power Board	O I				-	-
HP/LP Board	O I				-	-
Sync/Encoder Board	O I				-	-
Data Board	O I				-	-
Video Receiver Board	O I				-	-
Front End Board	O I				-	-
Audio/Intercom Board	O I				-	-
External Video Board	O I				-	-
Monitoring Board	O I				-	-
FM Transceiver Board	O I				-	-
Aux Receiver Board	O I				-	-
DSC Interface Board	O I				-	-
ENG Headset Board	O I				-	-
Local Power Board	O I				-	-
Digital Output Board	O I				-	-
SDTV Output Board	O I				-	-
Board Diagnostics >>						
Power Board >>					-	
Triax Status	O I	DCPWR..ACODC	-	-	-	See Section "Triax Status Indications"
Local Power Status	O I	Ok,NotOK	-	-	-	-
Power Overheated	O I	Yes,No	-	-	-	-
Fan	O I	Ok,NotOK	-	-	-	-
Sync/Encoder Board >>		Yes,No				
Reference Available	O I	Yes,No	-	-	-	-
Generator Lock	O I	Yes,No	-	-	-	-
Burst Lock	O I	Yes,No	-	-	-	-
Sync lock	O I	Yes,No	-	-	-	-
Data Board >>						
Boot Software Id	O I	0..255	-	-	-	-
Base Station 12NC	O I	0..9999	-	-	-	-
Base Station Status	O I	0..255	-	-	-	-
Aux Receiver Board >>						
Carrier Detected	O I	Yes,No	-	-	-	-
Audio/Intercom Board >>						
Self test	O I	exec	-	-	-	-
ENG Test Tone Intern	O I	Run,OK,Error	-	-	-	-
PROD Test Tone Intern	O I	Run,OK,Error	-	-	-	-
PROG Test Tone Intern	O I	Run,OK,Error	-	-	-	-
ENG Test Tone Studio	O I	Run,OK,Error	-	-	-	-
PROD Test Tone Studio	O I	Run,OK,Error	-	-	-	-
ENG Headset Board >>						
Self test	O I	exec	-	-	-	-
Test Intern	O I	exec	-	-	-	-
Test Studio	O I	Run,OK,Error	-	-	-	-
Test Tone Mic.BS	O I	Run,OK,Error	-	-	-	-
Test Tone Tr/Flr.Mic	O I	Run,OK,Error	-	-	-	-
Test Tone Cam.Mic	O I	Run,OK,Error	-	-	-	-
Communications Diag. >>						
Camera Connected	O I	Yes,No	-	-	-	-
OCP Connected	O I	Yes,No	-	-	-	-
MCP Connected	O I	Yes,No	-	-	-	-

List of Abbreviations

Abbreviation	Meaning
adap	adapter
agc	automatic gain control
awb	automatic white balance
bal	balance
cam	camera
ch	channel
cont	contour
ctemp	colour temperature
ctl	control track longitudinal
cus	customer
df	drop frame
dyn	dynamic
exec	execute
exp	exposure
ext	external
ext	extended
flt	filter
fr	front
frm	frame
f-run	free run
hd	head
hr	hour
ind	indicator
info	information
interv	interview
intv	interview
ir	infra-red
lvl	level
man	manual
max	maximum
mic	microphone
min	minute
min	minimum
mom	momentary
mon	monitor
nam	non-additive mix

Abbreviation	Meaning
nd	neutral density
ndf	no drop frame
ocam	camera operator file
ocard	smart card operator file
op	operation
oper	operator
outp	output
ovl	overload
pin	personal identification
number	
r/w	read/write
re	rear
repl	replay
r-run	record run
rst	reset
sawt	sawtooth
scam	camera scene file
scard	smart card scene file
sec	second
sel	select
srch	search
st	stereo
std	standard
str	stretch
tc	time code
tm	timer
ub	user bits
unbal	unbalanced
und	underload
var	variable
ver	version
vert	vertical
vf	viewfinder
wa	wide angle
wh	white
wrn	warning
wrx	wireless receiver

Section 4

Replacements

This section gives information on the procedures to follow when replacing printed circuit boards and mechanical components at first line level.

Contents

Introduction	4-2	Opening The Base Station	4-4
Power	4-2	Replacing Dust Filters	4-5

Introduction

The instructions given in this section are restricted to those modules which can be replaced at the first line service level. These modules include:

- The printed circuit boards
- The connector boards
- The front panels


After a printed circuit board has been replaced it is sometimes necessary to carry out adjustments to match the new boards to your base station and so maintain the performance levels. The relevant adjustment procedures are given in Section 4.

The procedures for removing the modules should be followed in reverse order when remounting the units.

Power

Removing the Power Unit

Remove the screw at the rear of the power unit. With your thumb push up the lever, as shown on the picture below, and pull the Power Unit out of the Base Station.




Locking the Power Unit

Put the Power Unit in the leading and push the Power in the Base Station till the locking clicks.


Check if the Power Unit is correct locked.

The correct and wrong locking positions are shown in the pictures below.




Opening The Base Station


House with top mounted



To remove top, bend both sides outwards and lift backside as shown on the picture






Slide top backwards and lift from house



Replacing Dust Filters


Side-inlet

1. Remove 4 screws.
2. Slide back support with dust filter out of base station.
3. Remove dust filter.
4. Connect clean dust filter to back support
5. Slide back support with dust filter into base station
6. Fix back support with 4 screws



Front-inlet


1. Remove PCB frontplate.




2. Remove dust filter.

3. Place clean dust filter

4. Place PCB frontplate back




5. Remove frontplate power supply



6. Remove dust filter

7. Place clean dust filter

8. Place front plate power supply back



Section 5

Diagnostics

This section contains an explanation of the internal diagnostic system of the base station. The diagnostic messages and the block diagrams are a useful help when fault finding.


Contents

Diagnostic LED Indications	5-2	Board identification	5-4
Triax diagnostic indications	5-3	Sync/Encoder HD board status	5-5

Diagnostic LED Indications

LED Test

When the power to the Base Station is switched on camera communication and on-air LEDs light sequentially. If a LED does not light during start-up that LED is probably defective.



1 Camera Communication

This green LED lights when the communications between Camera and Base Station are OK.

2 Power Switch and indicator

Switches the power supply to the Base Station on and off. A built-in light lights to indicate that power is being supplied to the Base Station.

3 Base Station

This green LED lights when the local power supplies to the Base Station are present.

4 Camera indicator - Test

This bicolour TEST LED lights red or yellow to indicate the Camera and Triax status:

- Red lights continuously – Triax short circuit.
- Red flashes – Triax open circuit.
- Yellow – Camera power switched off with the Operational or Master Control Panel.

5 Camera indicator - Connected

This green CONNECTED LED lights when the Camera is connected and the Camera power is not switched off by the MCP, OCP or Base Station menu.

Diagnostic indicators for camera power

Communication	Test	Connected	
off	off	green	Camera power switched off by the camera power switch.
off	yellow	off	Camera power switched off by the MCP, OCP or base station menu.

Triax diagnostic indications

Camera test LED (4) flashes red

A red flashing camera test LED (4) indicates an open triax connection (no camera is connected). Other indicators of this condition are:

OCP: Triax LED Flashes red
MCP: *DIAGNOSE \ TRIAX - OPEN*
Menu: *Diagnostics \ Communications \ Camera Connected -No*


Camera test LED (4) lights continuously (red)

A continuously lighting red camera test LED (4) indicates a short circuit in the triax connection (or an interrupted inner core). Other indicators of this condition are:


OCP: Triax LED red (continuously)
MCP: *DIAGNOSE \ TRIAX - SHORT*
Menu: *Diagnostics \ Board Diagnostics \ Power board \ Triax Status -TSHRT, COPEN or CSHRT (The interpretation of these messages is shown below)*

COPEN

Indicates a connection between outer and inner shield or between core and outer shield (when a camera is not connected).




It also indicates an interrupted inner core when both shields are connected correctly (when a camera is connected).




CSHRT

Indicates a short circuit between the core and the inner shield.




TSHRT

Indicates a short circuit between the inner shield, the outer shield and the core.



SOPEN



Indicates an open connection in the outer shield of the Triax cable or connector(s).



Precautions to avoid Triax problems

- Only use triax cable (with three conductors).
- Ensure that triax connectors (camera, CPU and extension cables) fit snugly into each other.
- Verify that there is no interruption in all three conductors of the triax cable before deploying (including extension triax cables).

Board identification



Sync/Encoder HD board status

LED indicators on the Sync/Encoder board show the status of the board and the signal locking:

Init. Fail:

- lights (red) if there is a configuration or initialisation error or if the bus clock or video sync pulses are missing.

Sync Lock:


- lights (green) if the Hor. and Vert. lock is OK.

Ext. Ref. Avail.:

- lights (green) if an external sync. signal is present.

Burst Lock:

- lights (green) if the subcarrier/H-phase lock is OK.



Section 6


Service Parts

Contents


Parts list & Exploded Views	6-2
-----------------------------------	-----

Parts list & Exploded Views


Service parts	Code Number	Used in	NAME
1.Sync Encoder HD BS	3922 406 88731	LDK4502/00	Standard Base Unit HDTV
2.Video Receiver HD BS	3922 406 88621	LDK4502/00	Standard Base Unit HDTV
3. SDTV Output HD BS	3922 406 88721	LDK4531/20	SDTV Output HD Module
4.Data Board BS	3922 406 87681	LDK4502/00	Standard Base Unit HDTV
5.Audio/Intercom BS	3922 406 87691	LDK4540/10	2CH Audio & 2/4 Wire Intercom
6.FM Transceiver HD BS	3922 406 89901	LDK4502/00	Standard Base Unit HDTV
7.Monitoring HD BS	3922 406 88741	LDK4560/20	Monitoring HD Module
8.BNC Connectorboard HD BS	3922 406 88841	LDK4502/00	Standard Base Unit HDTV
9.Signal Interconn BS	3922 406 87771	LDK4502/00	Standard Base Unit HDTV
10.DSC Interface Board HD BS	3922 406 88831	LDK4502/00	Standard Base Unit HDTV
11.Digital Output HD BS	3922 406 89871	LDK4502/00	Standard Base Unit HDTV
12.Signal Connector Board	3922 406 88221	LDK4502/00	Standard Base Unit HDTV
13.Subboard	3922 406 88231	LDK4502/00	Standard Base Unit HDTV
14.Ext Video Input HD BS	3922 406 88811	LDK4530/20	Ext Video Input HD
15.Power Module	3922 407 30681	LDK4510/10	Power Module
16.Triax Assy Fischer	3922 407 30531	LDK4521/10	Triax Module HDTV-Fischer
17.Triax Assy Trilock	3922 407 30551	LDK4521/20	Triax Module HDTV-Trilock
18.Triax Assy ARD	3922 407 30571	LDK4521/30	Triax Module HDTV-ARD
19.Triax Assy LEMO 4	3922 407 30591	LDK4521/40	Triax Module HDTV-LEMO 4
20.Triax Assy LEMO BBC	3922 407 30611	LDK4521/50	Triax Module HDTV-LEMO BBC
21.Triax Assy LEMO 3	3922 407 30631	LDK4521/60	Triax Module HDTV-LEMO 3




22.Back Plate Blind 3922 407 33321
Used in **LDK4502/00**
..... **Standard Base Unit HDTV**




23.Front Plate Assy HD BS 3922 407 35741
Used in **LDK4502/00**
..... **Standard Base Unit HDTV**



24.Triax Assy Wired 3922 407 34551
Used in **LDK4521/10**
..... **Triax Module HDTV-Fischer**
Used in **LDK4521/20**
..... **Triax Module HDTV-Trilock**
Used in **LDK4521/30**
..... **Triax Module HDTV-ARD**
Used in **LDK4521/40**
..... **Triax Module HDTV-LEMO 4**
Used in **LDK4521/50**
..... **Triax Module HDTV-LEMO BBC**
Used in **LDK4521/60**
..... **Triax Module HDTV-LEMO 3**



25.Motherboard BS Service Assy .. 3922 407 35471
Used in **LDK4502/00**
..... **Standard Base Unit HDTV**



Three rectangular pieces of aged parchment or leather are shown against a white background. The piece on the left is the largest and features a prominent, irregular yellowish-brown border. The middle piece is a narrow, vertical strip with a mottled, brownish-grey surface. The piece on the right is a smaller, vertical strip, also showing a mottled texture with shades of brown and grey. All three pieces exhibit signs of age, including uneven coloration and some surface wear.

THOMSON

Camera communication On Air Mains Base Station Camera Test Connected

Camera Base Station



Base Station	Service Parts
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20
21	21
22	22
23	23
24	24
25	25
26	26
27	27
28	28
29	29
30	30
31	31
32	32
33	33
34	34
35	35
36	36
37	37
38	38
39	39
40	40
41	41
42	42
43	43
44	44
45	45
46	46
47	47
48	48
49	49
50	50
51	51
52	52
53	53
54	54
55	55
56	56
57	57
58	58
59	59
60	60
61	61
62	62
63	63
64	64
65	65
66	66
67	67
68	68
69	69
70	70
71	71
72	72
73	73
74	74
75	75
76	76
77	77
78	78
79	79
80	80
81	81
82	82
83	83
84	84
85	85
86	86
87	87
88	88
89	89
90	90
91	91
92	92
93	93
94	94
95	95
96	96
97	97
98	98
99	99
100	100

Base Station

Base Station	Service Parts
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	10
11	11
12	12
13	13
14	14
15	15
16	16
17	17
18	18
19	19
20	20
21	21
22	22
23	23
24	24
25	25
26	26
27	27
28	28
29	29
30	30
31	31
32	32
33	33
34	34
35	35
36	36
37	37
38	38
39	39
40	40
41	41
42	42
43	43
44	44
45	45
46	46
47	47
48	48
49	49
50	50
51	51
52	52
53	53
54	54
55	55
56	56
57	57
58	58
59	59
60	60
61	61
62	62
63	63
64	64
65	65
66	66
67	67
68	68
69	69
70	70
71	71
72	72
73	73
74	74
75	75
76	76
77	77
78	78
79	79
80	80
81	81
82	82
83	83
84	84
85	85
86	86
87	87
88	88
89	89
90	90
91	91
92	92
93	93
94	94
95	95
96	96
97	97
98	98
99	99
100	100

Base Station

Base Station

Base Station


Base Station

Base Station

Base Station

Base Station

31.Fan Assy 3922 407 33571
Used in **LDK4510/10**
..... **Power Module**




32.Back Plate Fan Power 3922 407 33581
Used in **LDK4510/10**
..... **Power Module**




33.Set of Brackets Front 3922 407 33841

Used in **LDK4502/00**
..... **Standard Base Unit HDTV**



34.Fuse Holder USA 2432 029 01004
Used in **LDK4510/10**

35.Fuse 10A 250V 6,3 x 32 2422 086 00386
Used in **LDK4510/10**
..... **Power Module**



36.Fuse Holder EUROPE 2432 034 20201
Used in **LDK4510/10**

37.Fuse T 4A 250V 5 x 20 2422 086 01193
Used in **LDK4510/10**
..... **Power Module**

